USER'S MANUAL

3.5 INCH COMBO HDD ENCLOSURE

Features and Specification：

- ▲ Interface standard : USB2.0 /IEEE1394A
- ▲ Connectors/Cables: USB /1394 connectors and USB /1394 Cables
- ▲ Data transfer rate: USB2.0:High Speed up to 480Mbps / IEEE1394A up to 400Mbps.
- ▲ Ideal for backup ,and storage files.
- ▲ Truly Plug and Play automatic system configuration .
- ▲ Windows device drivers automatic installation.

Requirements：

- ✧ IBM or Compatible PC / Apple iMac G4
- ✧ USB 2.0 HOST /IEEE1394A HOST.
- ✧ Windows 2000, Windows XP, Windows ME or Windows 98SE operating system /Mac OS 10.X or above

Packing Contents：

Item
3.5 Inch HDD Enclosure
USB/1394 Cable
Screws
Power Adaptor
CD Driver / User's manual

Hardware Installation：

Notice:First,please set up the jump for Master type in your HDD as diagram 1 and 2.



(1)JUMP VIEW



(2)JUMP VIEW



(3) Connectors View

Windows 98SE Driver Installation:

1. Please insert CD into the CD-ROM.
2. Please double click “Setup.exe”.

3. Please select “Next” to continue.


INITIO Win98 USB Driver v1.27
Welcome to the INITIO Win98 USB Driver v1.27 Setup Wizard
The installer will guide you through the steps required to install INITIO Win98 USB Driver v1.27 on your computer.
WARNING: This computer program is protected by copyright law and international treaties. Unauthorized duplication or distribution of this program, or any portion of it, may result in severe civil or criminal penalties, and will be prosecuted to the maximum extent possible under the law.
Cancel
< Back
Next >

4. Please select “Next” to continue.


INITIO Win98 USB Driver v1.27
Select Installation Folder
The installer will install INITIO Win98 USB Driver v1.27 to the following folder.
To install in this folder, click "Next". To install to a different folder, enter it below or click "Browse".
Folder:
C:\Program Files\INITIO\INITIO Win98 USB Driver v1.27\
Browse...
Disk Cost...
Cancel
< Back
Next >


INITIO Win98 USB Driver v1.27
Confirm Installation
The installer is ready to install INITIO Win98 USB Driver v1.27 on your computer.
Click "Next" to start the installation.
Cancel
< Back
Next >

5. Please click “Close”.



6. Please click “Yes” to restart PC.


INITIO Win98 USB Driver v1.27
You must restart your system for the configuration changes made to INITIO Win98 USB Driver v1.27 to take effect. Click Yes to restart now or No if you plan to manually restart later.
Yes
No

7. Please click “Disk drivers” and double click your Brand of HDD under “Device Manager ”.



8. Please click “Settings” to continue.
9. Please click “Removable” and click “OK” to re-start your PC.



10. “My Computer” will appear the “Removable Disk”, please format your HDD if you use HDD first.



Win2000 /XP Installation :

1. Please click “My Computer”and click “Manage” to initial your HDD if you use HDD first .



2. Please click “Disk Management” and click “Removable Disk” to format HDD .



3. Please select “File System” and click “OK”.



4. Please click “OK”.

Format G:
WARNING: Formatting will erase all data on this volume.
To format the volume, click OK. To quit, click Cancel.
OK
Cancel

5. “My Computer” will appear “Removable Disk “, you can start to use it now.



Windows 98SE Driver Installation (For 1394 interface):

1.Please link your HDD to1394A port on PC ,then click “Device Manager” under “System Properties”.



3. Please click “Disk drivers” and double click your Brand of HDD, then double click it to continue.



3. Please click “Settings” and click “Removable”,then click “OK”to continue.



4.Windows will ask you to restart PC,please click “Yes” to restart your PC.


System Settings Change
You must restart your computer before the new settings will take effect.
Do you want to restart your computer now?
Yes
No

5. “My computer” will appear “Removable Disk”,please format HDD if you use HDD first.Now,you can start to use HDD enclosure.